

FBYC Flag Room Chromecast Audio or Bluetooth Music Controls



<p>Turns speakers on or off ON UP /DOWN OFF Dance floor and Seating must be off for outside to work</p>	<p>Leave Up LOCAL</p>	<p>DOWN (TAPE) CHROMECAST UP (TUNER) BLUETOOTH</p>
---	---------------------------	--



<p>MICROPHONE LEVELS Leave at 0</p>	<p>VOLUME CONTROLS Start at 7 and adjust as appropriate</p>	<p>BASS & TREBLE Leave at 0</p>	<p>LED Doesn't Work</p>	<p>POWER SWITCH Up ON Down OFF</p>
---	---	---	-----------------------------	--

This is a commercial 70 volt system – Please do not connect or disconnect anything unless you are familiar with this type of equipment – Shock or equipment damage may occur from improper connections